


Steppermotors

Stepper Drivers

Connect all the wires according to the the picture. You can choose your DIR and PUL pinnumbers on the breakout board and set them in MACH3.



Computer with MACH3